


Reinforcements (may be required):  
See «Reinforcement» section of the  
Analyzer software's report to have all  
material requirements (sizes,  
quantities, etc.)



CONCENTRATED TOP LOAD

DETAIL No.11